

Installation: Cowl or Roofline Vents for Tile Roof

1. Complete roofing to one course below the position for the tile vent.
2. Hold vent in position as centrally as possible between the rafters and mark where the vent spigot touches the underlay.
3. Cut underlay in a cross, fold up and back.
4. Insert felt weir, if using, under batten above opening, positioning it centrally above the hole.
5. Nail felt weir to the batten.
6. Nail felt over the battens.