

TERMINATION BAR

- 1) Install EPDM Rubber membrane as normal allowing an extra 1 to 2 inches overlap on to adjoining roof
- 2) Fold back EPDM membrane and apply a bead of water cut off mastic along the length of the over lap.
- 3) Allow the EPDM membrane to fold back on to the Water cut off mastic and install Termination bar on top of the EPDM membrane
- 4) Trim back any excess EPDM membrane using stanley knife against the edge of the termination bar
- 5) Apply bead of Lap Sealant to edge of termination bar as double protection from water ingress

